


# WØBYU ANALOG Room Network



*All activity on 444.250 is digital but will be heard in the Room as analog. Analog activity in the Room will be heard as digital on the 444.250 repeater.*

**Conversion from digital to analog takes place on Yaesu servers**

Repeater audio to/from internet  
 NODE input to/from repeater  
 = Repeater

drawn by KØHCV

*Analog repeaters are connected to the Room using an HRI-200 because that is the only way to provide Analog audio into the Room. PDN's are Digital only.*